

# ROAD



# ARMOR

## 2002 - 2009 CHEVY KODIAK / GMC TOPKICK FRONT BUMPER INSTALL INSTRUCTION



### Warning!

Read the instructions completely before beginning the installation. Before tightening bolts check to make sure that there are no obstructions such as brake, fuel or electrical lines that may be damaged. Also keep in mind this is an aftermarket product and MAY require some minor shimming and or trimming, reaming etc. To fit properly.

### IMPORTANT NOTICE

IF YOU ARE RECEIVING THIS ROAD ARMOR PRODUCT RAW/UNCOATED.

BE SURE TO INSPECT AND OR TEST FIT YOUR PRODUCT TO ENSURE PROPER FITMENT AND ADEQUATE SURFACE PREPARATION BEFORE HAVING YOUR PRODUCT COATED, PAINTED, BED LINED, ETC.

ROAD ARMOR WILL NOT BE RESPONSIBLE FOR THE COST OF COATING YOUR UNIT IF ANY PROBLEMS WITH FIT OR FINISH ARE NOT NOTED AND ADDRESSED PRIOR TO HAVING YOUR PRODUCT COATED.

THANK YOU

### SUGGESTED LIGHTS THAT FIT THIS UNIT:

One Set of PIAA 510 - [www.piaa.com](http://www.piaa.com) - Part Numbers (5161, 5164, 5192, 5190, 5196).

OR

Warn 350F - [www.warn.com](http://www.warn.com) Part Number (82410).

One Set of PIAA 540 - Part Number (5461, 5462)



### TOOLS NEEDED

-Yourself and a few strong friends / bumper jack.  
( Don't worry, we're not calling you or your friends a "tool" )

- Socket set, Ratchet & Wrenches (metric & standard)  
( ... more than likely metric for your rig, cause everything's imported these days,  
and standard for your new bad ass Made in USA bumper.  
Road Armor thanks you for supporting the American Economy! )

- Common Sense a Tape Measure and a bit of Patience  
( And also a cold drink to celebrate afterwards )



**STEP 1 :** Make sure you have all necessary tools and hardware.

Hardware Kit Includes : ( all Grade 8 )

- ( 4 ) 1/2 Nuts
- ( 8 ) 1/2 Washers
- ( 4 ) 1/2 Lock washers
- ( 4 ) 1/2 Retaining clips
- ( 4 ) 1/2 x 2" Bolt Tabs

**STEP 2:** Uninstall OEM Bumper

- Park on a level surface
- Pop Hood
- Remove license plate
- Disconnect battery
- Unbolt the OEM bumper from the stock bracket.
- Unbolt the 4 side bolts on the spring purch to remove the OEM bumper mounts.

**STEP 3:** Install RoadArmor Bumper

- Place the 1/2 bolt tabs through the holes on the bumper and use the retaining clips to keep the bolts from falling back when installing the bumper.

-Use a small socket to help push the retainers clips on.

Pictures 3-4

- Mount up the brackets to the frame using the OEM hardware. Leave the hardware finger tight.

Pictures 1-2

- Install the Road Armor bumper onto the mounts using the 1/2 hardware.
- Once that's complete measure the gaping on both sides to ensure the proper alignment. Use a body line or the headlight to measure from.
- Now that everything is all mounted up and aligned, tighten all the hardware and add the Road Armor emblem.

